

hp
digital entertainment center
de100c



owner's guide

store

organize

discover

play

table of contents

1 introduction 7

- getting started 8
 - about this guide 9
- using the remote control and front panel 10
- button overview 12
- typing with the onscreen keyboard 18
 - the keyboard's keys 19
- the internet connection 20
 - dial-up prompt 20
 - retrieving cd information 20
 - using the info button 20
 - connecting to internet radio 21
 - connecting to the internet guide 21
 - connecting for updates 21
- power modes 22
 - on/off and sleep mode 22
 - screen saver 22
- where to find help 23

2 playing CDs and recording music to the library 25

- playing a CD 26
 - what's displayed 27
- recording CD tracks 28
 - recording all tracks 28
 - what's displayed 29
 - recording selected tracks 30
- retrieving CD information 31

consolidating dial-up connections when recording 32
copying music from a networked PC 33

3 enjoying your music library 35

sorting and playing your music 36
 what's displayed 37
library navigation: select vs. play 38
searching within your library 39
creating and playing playlists 40
 naming a playlist 40
 adding music to a playlist 40
 playing your playlists 41
 modifying playlists 41
 clearing a playlist 41
editing CD and track information 42
deleting music from your library 43

4 taking your music with you 45

writing to a CD 46
 selecting a music format 48
 erasing cd-rw media 48
putting your music on a portable device 49
 supported devices 49
 downloading to a portable device 49

5 listening to internet radio 53

- understanding internet radio 54
 - connection 54
 - buffering 54
 - graphics 55
 - station availability 55
- finding and playing internet radio stations 56
 - featured stations 56
 - last station played 56
 - browse stations 56
 - my favorites 57
 - search all stations 57

6 exploring music online 59

- entertainment features 60
- music finder 60
- searching & shopping for music 61
- your shopping cart 61

7 setting your preferences 63

- audio settings 64
 - encoding rate 64
 - encoding format 65
 - audio test 65
- network settings 66
 - basic settings 66
 - advanced settings 67

- scheduling 70
 - time and date 70
 - time zone 70
 - update time 70
- external devices 71
 - supported devices 71
- general information 72
 - registration info 72
 - about your de100c 73
 - copyright information 73

8 installing and setting up 75

- step 1: get ready 76
 - unpack your digital entertainment center 76
 - check your internet readiness 77
 - choose a location 77
- step 2: connect 78
 - connect the audio 79
 - connect the video 80
 - connect dial-up or broadband 81
 - power up 81
- step 3: check setup 82
 - turn on your system 82
 - about component with multiple inputs 82
- step 4: configure 84
 - test the audio 84
 - set the time zone 84
- step 5: connect to the internet 85
 - dial-up 85
 - broadband 88
- step 6: register 91

- finding network settings on your PC 92
 - locating the network mask, internet gateway, and name server 92
 - locating the web proxy 94

9 support and customer information 97

- support and services 97
 - troubleshooting 97
 - hp customer care 97
 - repairs and service 98
- hp upgraded warranty statement 99
- warranty statement 100
- privacy statement 102
- product certifications 105

index 109

introduction

Welcome to HP's Digital Entertainment Center, the Internet-connected stereo component that brings the Internet music experience to your living room with the click of a button.

With the digital entertainment center, you can:

- store and automatically catalog up to 750 CDs
- create and enjoy playlists of your favorite tracks
- take your favorite music anywhere by burning tracks to CD or copying them to your portable MP3 player
- download music, purchase CDs, and listen to Internet radio in your living room

— and more.

This guide explains how to use your digital entertainment center. For simple, step-by-step instructions on installing the device, see the setting up your hp digital entertainment center poster. For more detailed information on installation and connectivity, see "installing and setting up" on page 75 in this guide.

1

in this chapter...

getting started
— page 8

using the remote control
and front panel
— page 10

button overview
— page 12

typing with the onscreen
keyboard
— page 18

the internet connection
— page 20

power modes
— page 22

where to find help
— page 23

getting started

Once you've installed and set up your digital entertainment center, you'll want to quickly familiarize yourself with the basics.

- learn to use the controls

You can operate the digital entertainment center with the remote control or from the front panel. This chapter gives you a look at all the buttons and their functions, as well as the onscreen keyboard.

- understand the Internet connection

A quick overview helps you understand how the digital entertainment center uses the Internet to retrieve information, play music and more — as well as how features are kept up to date.

This chapter also explains the digital entertainment center's power modes and tells you where to find help.

about this guide

The chapters that follow show you how to store, organize and play your music, your way.

this chapter...		explains how to...
2	playing CDs and recording music to the library	get music onto your digital entertainment center
3	enjoying your music library	find, organize, and listen to music in your library
4	taking your music with you	burn CDs and copy music to your portable device
5	listening to internet radio	find and play stations you know as well as discover new favorites
6	exploring music online	explore a world of discovery and entertainment, and easily find and shop for music
7	setting your preferences	use and change the digital entertainment center's settings
8	installing and setting up	install and configure your digital entertainment center
9	support and customer information	contact HP Customer Care and presents the HP Privacy Statement and other notices

tip

Make sure you point the remote at the front of the digital entertainment center — not at your TV screen.


using the remote control and front panel

The remote control lets you lean back, relax, and operate your digital entertainment center from across the room. Its buttons are described in “button overview,” starting on page 12.



The digital entertainment center's infrared receiver requires an unobstructed signal from the remote control. If you place your digital entertainment center inside a cabinet, be sure the blue window area is not blocked from view. (Placing it behind glass is fine.)

The front panel is designed to give you quick control over the digital entertainment center's simpler functions, which don't require the TV interface for navigation. Not all functions are available from the front panel. Its buttons are described in "button overview," starting on page 12.











note The digital entertainment center's back panel is illustrated on page 78.





tip






If your digital entertainment center stops responding, you can reset the system by pressing and holding the **Power** button for six seconds to power off, and then powering on again.

button overview




	button	description	details
basic operation	 Power	Press and release for simple power on/off.	When turned off this way, the digital entertainment center enters sleep mode and the fan runs quietly. Restart is quick.
		Press and hold for six seconds for full power down.	When powered down this way, the digital entertainment center's fan turns off and the system performs self-maintenance. Restart takes one to two minutes; the system is refreshed.
	 CD tray open/close	Open and close the CD tray.	Manually pushing the CD tray closed may damage the device.
	 NOW PLAYING	Return the display to either: <ul style="list-style-type: none"> — the screen from which the currently playing audio item was launched, or — the currently playing video item 	

	button	description	details
mode selection	 CD	Go to the CD play and record functions.	
	 LIBRARY	Go to the top level of all Library functions.	From here you can access your recorded music, playlists, CD-Writer and portable functions, and music you've downloaded.
	 INTERNET RADIO	Go to Internet Radio.	
	 INTERNET GUIDE	Go to the Internet Guide.	
	 HOME	Go to the top level of all functions.	From here you can choose CD, Library, Internet Radio, Internet Guide, or Settings.

		button	description	details
special functions		ADD	Add an item to a list.	
		SHUFFLE/ REPEAT	Toggle between repeat mode, shuffle mode, both repeat and shuffle, and regular play.	Graphics on the TV and on the front panel are visible when shuffle and/or repeat are in use.
		INFO	Retrieve CD, artist, or radio station information from the Internet.	Choices include discography, related artists, album details, and more.
		OPTIONS	Bring up a menu of operations that can be performed on the currently selected item. Onscreen Help is also available through OPTIONS.	Pressing OPTIONS a second time closes the pop-up menu.

	button	description	details
navigation	 BACK	Return to the previously displayed screen or close transient screens, such as the onscreen keyboard, pop-up menus, and add pads.	
	 SEL	Select the currently highlighted item.	When choosing artist or album names, etc., SEL navigates down to the next level, displaying the item's contents. At the lowest level — track title — SEL also functions as the Play or ADD button.
		<p>Up and Down arrows navigate through onscreen items.</p> <p>On most screens:</p> <ul style="list-style-type: none"> — Left goes to the previous screen in the current task hierarchy (similar to BACK). — Right goes to the next screen in the current task hierarchy (similar to SEL). 	<p>Navigation wraps up and down the screen. For example, pressing Down from the last item brings you to the first item.</p> <p>In the onscreen keyboard, navigation also wraps left and right.</p>
	 PG UP	Moves up, page by page, through lists that are longer than one screen.	
	 PG DN	Moves down, page by page, through lists that are longer than one screen.	

	button	description	details
transport controls	 Rewind/ skip back	To rewind the currently playing song, press and hold. To skip to the beginning of the song, press and release. To skip back through the songs in the currently playing list, repeatedly press and release.	
	 Play	Play the currently highlighted item.	You can press Play for any highlighted item, including an album, an artist – even an entire genre – and all the songs within that highlighted item play.
	 Fast forward/ skip forward	To move forward within the currently playing song, press and hold. To move to the beginning of the next song, press and release. To move forward through the songs in the currently playing list, repeatedly press and release.	

	button	description	details	
transport controls		Record	Record the current item or list.	When you first insert a CD, you can simply press Record to record the entire CD to the digital entertainment center.
		Stop	Stop the currently playing/recording/downloading item (audio or video).	
		Pause	Pause the currently playing item.	To resume play, press Pause again or press Play.

tip

When the keyboard appears, it sometimes contains information you want to erase before you begin typing (such as Playlist #1). To erase the entire field quickly, simply select **clear**.

typing with the onscreen keyboard

The digital entertainment center's onscreen keyboard appears whenever you choose a function that requires typed input. You use it to enter information about your Internet connection, to register, to name playlists, to edit CD and track information, and more.

Use the arrow keys on the remote or front panel to navigate around the keyboard. Press SEL to select the key that's highlighted.

Navigation wraps around the keyboard, both left/right and up/down.



the keyboard's keys

command	description
done	accepts the entry as shown in the typing field and closes the onscreen keyboard
cancel	Cancels any changes made in the current typing session and closes the onscreen keyboard
clear	clears the entire typing field
delete	deletes the keystroke preceding the flashing cursor (functions like backspace on a computer keyboard)
left arrow	moves the cursor position to the left
right arrow	moves the cursor position to the right
case	changes the alphabetical characters to upper or lower case

tip

If you press the remote's [BACK](#) button while the keyboard is onscreen, the keyboard disappears and your typing is not saved, just as if you had selected [cancel](#). To finish and save your typing, select [done](#).

tip

dial-up users

If you need your phone line while the digital entertainment center is connected to the Internet, the fastest way to break the connection and free the line is to quickly press and release the digital entertainment center's [Power](#) button.

the internet connection

The digital entertainment center performs some functions on its own, and some functions require connection to the Internet. If you're a dial-up user, you need to be aware of when these connections occur. A successful connection, of course, requires the appropriate dial-up line to be free.

If you're a broadband user, the digital entertainment center's Internet access should be transparent to you.

dial-up prompt

When the digital entertainment center is set up for dial-up use, the default procedure is to prompt the user each time a connection is required. When the prompt appears, select Yes to make the connection. To decline the connection, select No or ignore the prompt (it times out in 20 seconds).

If you want the connection to occur automatically (without prompting), change the Prompt before dialing setting under Advanced network settings to No.

See "prompt before dialing" on page 69 for details.

retrieving cd information

When you insert a music CD for the first time, the digital entertainment center makes a brief connection to the Internet to retrieve the album, artist, genre and track information. If for any reason the data isn't automatically retrieved when you first insert the CD, you can make this connection manually by pressing **OPTIONS**, then choosing **cd info**.

For more information on this function, see "retrieving CD information" on page 31.

using the info button

In CD or Library mode, when you press the **INFO** button and then choose discography or related artists from the pop-up menu, the digital entertainment center connects to the Internet to access the requested information.

connecting to internet radio

To play Internet radio stations, the digital entertainment center must be connected to the Internet during the entire play session. If you're connecting to the Internet via dial-up, the connection engages the phone line, just as a PC-based Internet connection does.

See "listening to internet radio" on page 53 for a full explanation of Internet radio's functions and behavior.

connecting to the internet guide

The material presented on the Internet guide is updated regularly and streamed live to your digital entertainment center. Therefore, the digital entertainment center must be connected to the Internet while you're using any of the Internet guide's features.

See "exploring music online" on page 59 for more on the Internet Guide.

connecting for updates

As features are added to the HP Digital Entertainment Center and its software is enhanced, HP updates your device automatically. You won't see large-scale changes to the features or presentation, but you will occasionally find new options available to you. You don't need to take any action to receive these updates. If you want to change the scheduled update time, see "update time" on page 70 for details.

At update time, the digital entertainment center turns on (if it's in sleep mode), performs any appropriate internal maintenance, and connects to the digital entertainment portal if it needs to download new updates. Once the device has gathered the available updates, it disconnects any dial-up connection and then applies the updates internally. The front panel displays an Update Mode message along with instructions not to power off the device, and the Power button is disabled to prevent an inadvertent error. When finished, the digital entertainment center returns to the mode it was in.

If for any reason the device cannot reach the digital entertainment portal at update time, the process reschedules itself for the next day.

tip

After the digital entertainment center performs an Internet-related operation, it holds the connection open for a short period of time.

If another Internet-related operation occurs while the connection is still live, it is handled immediately, since there is no delay to dial in again.

caution

Unplugging the device during update could cause damage to the digital entertainment center's software.

tip

If your digital entertainment center stops responding, you can reset the system by pressing and holding the [Power](#) button for six seconds to power off, and then powering on again.

power modes

on/off and sleep mode

When you quickly press and release the Power button, the digital entertainment center processes for a moment then enters sleep mode (rather than turning off completely), and the cooling fan runs quietly. This sleep mode allows the digital entertainment center to power up quickly when you turn the device back on. From sleep, the device powers on to the home screen.

You can power down the device completely by pressing and holding the Power button for six seconds. The cooling fan will turn off and the software will reset.

If the device has been powered off or has experienced a power loss, the next power-on will require a one- to two-minute startup sequence and will bring you to the initial welcome screen.

screen saver

Because some TV screens may be susceptible to burn-in, or low-grade damage to the screen image when static images are displayed for an extended time, the digital entertainment center switches to a screen-saver mode when it is inactive for 10 minutes: the TV displays a screen saver and the front-panel display dims. To restore the regular views, press any button on the remote or the front panel. (The first button press simply refreshes the screen and is not processed.)

where to find help

Answers to many frequently asked questions are available onscreen at any time. Press **OPTIONS**, then select help.

For technical support, see “hp customer care” on page 97.

For more information on the HP Digital Entertainment Center, visit either:

- [www. hp.com/support/de100c](http://www.hp.com/support/de100c)
- or
- www. hp.com/go/dec

2

playing CDs and recording music to the library

The digital entertainment center's CD mode lets you:

- play CDs, just as you would on any CD player
- record CDs to the device, where the resulting MP3 files become part of your music library
- gather CD information for a CD, if for some reason the information wasn't retrieved the first time you inserted it

You can also record music to the digital entertainment center by copying it directly from a networked PC.

note To burn tracks from your library onto CD-R or CD-RW media, see "taking your music with you" on page 45.

accessing CD functions

To access cd functions, either:

- press CD on your remote or front panel:
- or
- select CD from the home menu



in this chapter...

playing a CD — page 26

recording CD tracks — page 28

retrieving CD information — page 31

consolidating dial-up connections when recording — page 32


copying music from a networked PC — page 33


tip

If you press [Play](#) or [Record](#) but don't hear music, make sure:

- your receiver's audio input setting is set properly
- the volume is turned up and is not muted


playing a CD

- 1 On the front panel, press the Open Tray button:  Insert a CD, then close the tray.





- 2 Select CD from the home menu, or press CD: 


The digital entertainment center retrieves the CD information — artist, album title, track titles, and genre — from the Internet. When the CD track titles appear, the first track is highlighted.

dial-up users It takes a minute or two for the digital entertainment center to dial-up and connect with the CD database.

- 3 If you want to start playing at a different track, use the arrow keys to highlight the track you want.
- 4 Press Play: 


The CD plays, beginning at the highlighted track. While playing, you can:

- Stop playing:  Press Play to start playing the selected track from the beginning.
- Pause playing:  Press Play or press Pause again to continue playing the selected track.
- Fast-forward or rewind:   These buttons let you quickly move forward or backward through the track.

- Shuffle/Repeat to randomly play your music or to repeat the selected music:  The shuffle and/or repeat icons appears in the lower left corner of your television and front panel when these functions are in use.

what's displayed

While you're playing a CD, your television displays the following:




tip

If you navigate to different screens while playing a CD, press **NOW PLAYING** at any time to return to this screen.

The currently playing track will be highlighted.

And the front panel shows this information:



tip

The digital entertainment center records about four times faster than it plays.

After the last track is recorded (a white dot next to each title means it has been recorded), you can press **Stop** to stop playing, then begin recording your next CD.

recording CD tracks


You can record all tracks on a CD to the digital entertainment center or select specific tracks to record. When you record them, tracks are:


- converted to MP3 format (if they are not already MP3 files)
- stored on the digital entertainment center's hard drive
- catalogued according to artist, album, genre, and track title

note You can retrieve the CD information later if your Internet connection is not available at the time of recording. See “retrieving CD information” on page 31. You also can edit the CD information. See “editing CD and track information” on page 42.

recording all tracks

The simplest recording operation is to record an entire CD. Here's how:

- 1 On the front panel, press the Open Tray button: 
Insert a CD, then close the tray.


- 2 Select CD from the home menu, or press CD: 

The digital entertainment center retrieves the CD information and displays it.

dial-up users It takes a minute or two for the digital entertainment center to dial-up and connect with the CD database. To make better use of your connection when recording multiple CDs, see “consolidating dial-up connections when recording” on page 32.


- 3 Press Record: 

The CD plays, beginning with the first track, and the digital entertainment center records the tracks to the hard drive.

To cancel, press Stop: 

what's displayed

While you're recording, your television displays the following:




tip

To ensure tracks are recorded without errors, all navigation is disabled during the record operation.

You can navigate around the digital entertainment center after recording is finished, even as play continues.

And the front panel shows this information:



dot identifies the track recording;
arrow indicates the currently playing track


time elapsed and track length
refer to the currently playing track


tip



To find out how much room is left on your hard drive, press [HOME](#). Select [settings](#), then select [general information](#), then [About de100c](#).


recording selected tracks

Here's how to record a specific set of tracks.


- 1 On the front panel, press the Open Tray button: 
Insert a CD, then close the tray.


- 2 Select CD from the home menu, or press CD: 
The digital entertainment center retrieves the CD information and displays it.


- 3 Use the arrow keys to highlight the first track you want to record:  

- 4 While the track is highlighted, press OPTIONS: 

- 5 Select record track. An add pad appears, and the track title is added to it.




- 6 To select another track to record, use the arrow keys to highlight it. Press ADD: 
Continue highlighting and adding until all of the tracks you want to record are on the add pad.

- 7 Press Record: 
The selected tracks play, and the digital entertainment center records the tracks to the hard drive.

To cancel, press Stop: 

retrieving CD information

The first time you insert a CD to play or record it, the digital entertainment center retrieves the CD information (artist and album name, track titles, etc.) over the Internet. If for some reason the data isn't retrieved when you first insert the CD, you can still play and/or record the CD without the information, then retrieve the information later. Here's how.


- 1 On the front panel, press the Open Tray button: 
Insert a CD, then close the tray.
- 2 Select CD from the Home menu, or press CD: 
- 3 Press OPTIONS: 
- 4 Select cd info. The digital entertainment center retrieves the CD information.

If you have already recorded the CD to the digital entertainment center, the information is automatically applied to the tracks in your library.

consolidating dial-up connections when recording

If you want to record from several CDs and you use a dial-up connection, here's the most efficient way to gather the CD information. This method lets you avoid repeated dial-ups (the longest part of the information gathering process) to make multiple database retrievals (a very short part of the process).

To gather CD information for several CDs:

- 1 On the front panel, press the Open Tray button: 
Insert a CD, then close the tray.

- 2 Press CD: 

The digital entertainment center retrieves the CD information.

- 3 When the CD track titles appear, remove the CD and insert another. This time the information appears quickly, because the Internet connection is already live.

note The digital entertainment center attempts to retrieve CD information only the first time a CD is inserted. If you insert a CD and the digital entertainment center does not attempt to retrieve its data, press **OPTIONS**, then select **cd info** to get the CD information.

- 4 Repeat steps 1 through 3 for all of the CDs you plan to record.

The digital entertainment center now recognizes each of the CDs you've inserted. It does not need to connect again when you play or record the CDs.

copying music from a networked PC

To copy MP3 files from your PC to your digital entertainment center, you can either:

- burn the files to CD and then record the CDs to your library (see “recording CD tracks” on page 28), or
- copy the files directly across your home network

To copy the files directly, your PC and your digital entertainment center must be networked together. In addition, you must enable file sharing on your digital entertainment center (see “file sharing” on page 68 for instructions).

To copy files directly:

- 1 On your PC, choose Start, then Run.
- 2 In the Run window's Open field, type the IP address of your de100c.

A window appears, containing a folder called import.

note To find the digital entertainment center's IP address, go to the digital entertainment center itself. From the home menu, select Settings, then Network settings. The IP address is displayed onscreen.

- 3 Locate the MP3 files on your PC that you want to copy. For example:
 - From Start, choose Find, then Files or Folders.
 - In the Named field, enter *.mp3.
 - Ensure that the Look In field is set to the drive you want to search.
 - Click on Find Now.
- 4 Select (highlight) the files you want and copy (drag) them to the import folder.

note You cannot copy files directly from the digital entertainment center to the PC.

tip

The copied files will quickly appear in your music library, catalogued with the same artist, album, genre and track titles as they were on your PC.

If you don't see the files right away, note that the digital entertainment center must be on, but idle, for about two minutes to perform the operation.

3

enjoying your music library

When you record CD or MP3 tracks, the music files become part of your library. Within your library, you can:

- sort, view, search, and navigate through your music
- play your music
- edit CD and track information
- delete tracks
- create and play playlists

You can also download tracks to a portable device and burn tracks from your library onto digital audio CD-R or CD-RW media. See “taking your music with you” on page 45.

accessing your library

To access your library, either:

- press LIBRARY on your remote or front panel:
- or
- select Library from the home menu



in this chapter...

sorting and playing your music — page 36

library navigation: select vs. play — page 38

searching within your library — page 39

creating and playing playlists — page 40

editing CD and track information — page 42

deleting music from your library — page 43


sorting and playing your music

You can sort your music to play any collection of tracks in your library, such as a complete CD, your entire collection by a specific artist, or all of a particular genre. (To create and play playlists, see page 40.)

To sort and play your music:

1 From the library menu, select Music. The following categories are displayed:


- Artists
- Albums
- Genres
- Track titles

2 Navigate to the category you want to view, then press SEL: 


The category's contents appear. Continue navigating and selecting until you have chosen the music you want to hear.

3 Press Play: 



All the tracks to be played are displayed, and play begins. While playing, you can:

— Stop playing: 



Press Play to start playing the selected track from the beginning.

— Pause playing: 

Press Play or press [Blue](#) again to continue playing the selected track.

— Fast-forward or rewind:  


These buttons let you quickly move forward or backward through the track.

— Shuffle/Repeat to randomly play your music or to repeat the selected music:  

The shuffle and/or repeat icons appears in the lower left corner of your television and front panel when these functions are in use.

what's displayed

While you're playing tracks in your library, your television displays the following:




tip

If you navigate to different screens while playing music in your library, press **NOW PLAYING** at any time to return to this screen.

The currently playing track will be highlighted.

And the front panel shows this information:



library navigation: select vs. play


The SEL and Play buttons have separate but overlapping functions. When any category is highlighted:

- SEL displays a list of all the items in that category
- Play plays all the music in that category

For example, if you press SEL while a genre is highlighted, the tracks within that genre will be listed. If you press Play while the genre is highlighted, all the tracks within that genre will play.

At the lowest level — track titles — SEL works just like Play: it plays the listed music, beginning with the highlighted track.


SEL and Play in library navigation




searching within your library

You can move quickly to a specific artist, track, or other item in your by using the search function. This feature is particularly useful when you've recorded a large amount of music to your digital entertainment center.

- 1 From the library menu, select Music.
- 2 Highlight the category you want to search within, such as Artists or Track titles.

Press SEL: 

- 3 Press OPTIONS: 
- 4 Select search.
- 5 Use the onscreen keyboard (detailed on page 18) to enter the first few letters of the item you're searching for, then select done on the keyboard.

The display will jump to the section of the music list that matches your search criteria. Use the arrow buttons to navigate further within the list.

note Search is not case sensitive.

tip

The search function looks for items alphabetically as they exist in the database.

If you're searching for an artist named, for example, John Blue, typing **BL** will not bring you to the correct area in your list; typing **JO** will.

tip

You can follow these steps to add music to a playlist any time.

The tracks you add will appear at the bottom of the playlist.


To change the order, see “modifying playlists” on page 41.

creating and playing playlists




A playlist is a collection of tracks that you choose and organize anyway you like. You can create up to 99 playlists of any length on your digital entertainment center.

note You can name your playlist first, then add music to it; or you can add music first, then rename the playlist.

naming a playlist


- 1 From the library menu, select Playlists, then highlight the list you want to rename.
- 2 Press **OPTIONS**: 
- 3 Select rename.
- 4 Use the onscreen keyboard to name your list, then select done.

adding music to a playlist

- 1 From the library menu, select Music.
- 2 Navigate down to the appropriate level and highlight the first item you want to add to the playlist. You can add items track by track, or you can add multi-track items, such as an entire album.
- 3 Press **OPTIONS**: 
- 4 Select add to, then select playlist.
- 5 Select the desired playlist. An add pad appears and the item is added to the list. If you add a multi-track item, all of the item's track titles appear on the add pad.
- 6 Continue adding items by navigating through the music list and pressing **ADD**: 
- 7 When finished, press **OPTIONS**: 



playing your playlists

To play a playlist:

- 1 From the library menu, select Playlists.
- 2 Highlight the playlist you want to hear.
- 3 Press Play: 


modifying playlists

You can add or delete tracks in a playlist, or change their order. To add to your playlist, see “adding music to a playlist” on page 40. To delete or move items in your playlist:

- 1 From the library menu, select Playlists.
- 2 Highlight the list you want to modify, then press SEL: 
The playlist's contents are displayed.
- 3 Highlight the item you want to move or delete, then press OPTIONS: 
- 4 Delete or move the item:
 - To delete it, select delete. The item is removed from the playlist.
 - To move it, select move. Use the arrow keys to move the item, then press SEL.

clearing a playlist

To clear a playlist:

- 1 From the library menu, select Playlists.
- 2 Navigate to the list you want to clear, then press OPTIONS: 
- 3 Select clear list. All tracks are cleared from the playlist.

tip

When you delete an item from a playlist, it is NOT removed from the library.

To delete tracks from your library, see “deleting music from your library” on page 43.

tip

Are you missing CD information?





The online database may not have information for some rare or obscure CDs.

However, if you record a CD and the information isn't automatically retrieved, try again to retrieve it before you enter it manually, as the information may have become available or your initial connection may have been faulty.

See "retrieving CD information" on page 31.

editing CD and track information

To edit or add to the CD and track information stored in your music library:

- 1 Highlight the item you want to edit, then press **OPTIONS**: 
- 2 Select edit. The information appears onscreen.
- 3 Highlight the category you want to edit, then press **SEL**: 
For some categories, a drop-down menu appears, with Use keyboard as the first item. For others, the onscreen keyboard automatically appears.
- 4 Either:
 - use the onscreen keyboard to make changes (see page 18) and select done when finished, or
 - highlight an item from the menu, then press **SEL**: 
- 5 If desired, select and edit another category.
- 6 When finished, press **OPTIONS**: 
- 7 Select done.



how changes are applied

If you edit:

- a track, the changes you make are applied to that track only
- an artist, album or genre, your changes are applied to all tracks listed for that artist, album or genre

deleting music from your library

To delete music from your digital entertainment center:

- 1 From the library menu, select Music, then navigate down to the appropriate level (for example, albums or track titles).
- 2 Highlight the item you want to delete, then press OPTIONS: 
- 3 Select delete. A confirmation pop-up appears onscreen.
- 4 Highlight delete, then press SEL: 

The item is deleted from your music library.

4

taking your music with you

The HP Digital Entertainment Center makes it easy to enjoy your music collection wherever you go. In addition to playing and organizing the music in your library, you can:

- write MP3 files or standard music files onto CD
- download MP3 tracks to a portable device

accessing the functions

Go to your library to make your music portable:

- press LIBRARY on your remote or front panel:
or
- select Library from the home menu



in this chapter...

writing to a CD
— page 46

putting your music on a
portable device
— page 49

tip

Once you've chosen music files to write to CD, the list is accessible until you write the CD (from the library menu, select [CD-Writer](#) to access the list).

When the writing process is complete, your list of songs is deleted.

If you want to create a list that remains available (such as to download to a portable device or just to listen to), build a playlist first, then add the playlist to your [tracks for writing](#) add pad).

See page 40 for instructions on playlists.



writing to a CD

The HP Digital Entertainment Center writes to CD-R and CD-RW discs that comply with the Digital Audio standard. Digital Audio CDs are widely available through consumer electronics retailers.


To create a CD on the digital entertainment center, you first compile the list of tracks you want to write to CD and choose a music format. Then you can refine the list before writing it to CD.

- 1 Place a blank Digital Audio CD (CD-R or CD-RW media) in the CD tray.
- 2 From the library menu, select Music or Playlists.
- 3 Navigate down to the appropriate level and highlight the first item you want to add to your CD.

You can add items track by track, or you can add multi-track items, such as an entire album or a complete playlist.

- 4 When the item is highlighted, press **OPTIONS**: 
- 5 Select add to, then select cd-writer.
- 6 Select the music format you want to use (see "selecting a music format" on page 48).
- 7 Continue adding items to the add pad by navigating through the music list and pressing **ADD**: 


note The digital entertainment center writes CDs at a speed up to 8x when you use digital audio CD-R discs and up to 4x when you use digital audio CD-RW discs.

- 8 When finished, press OPTIONS: 

The tracks for writing screen displays your list.

- To delete a track from the list, highlight the track, then press OPTIONS. Select delete.
- To change the order of the tracks, highlight a track, then press OPTIONS. Select move, and use the up or down arrow to move the item. When you are done, press SEL.
- To clear the entire list, press OPTIONS, then select clear.

If you have chosen too many tracks to fit on the CD or if any tracks on your list are not in correct MP3 format, you'll see an error message below the list. Scroll through the track list to see which tracks are marked won't fit or bad MP3?, then delete tracks from the list accordingly.


- 9 To write the list to CD, press OPTIONS: 
Select record all.

error message

If the disc in the drive is not writable or there is no disc present, you'll see an error message below the list. Ensure that:

- a disc is in the drive
- the disc is Digital Audio CD-R or CD-RW
- the disc is blank: the digital entertainment center cannot append files to a partially written disc (you can erase CD-RW media; see page 48)

To continue:

- 1 Replace or insert the media.
- 2 Press OPTIONS: 
- 3 Select record all.

tip


To ensure CDs are written without errors, all navigation (except [Stop](#)) is disabled while the CD is being written.

selecting a music format

This table will help you determine which CD format you want to use.

option	description	pros	cons
write a music CD	Converts MP3 files to standard music files.	Resulting CDs can be played on most CD players when using CD-R media, and on many CD players when using CD-RW media.	Compared to MP3, fewer tracks fit on CD (about 10-20 tracks, depending on file size).
write an MP3 CD (flat file system)	Writes MP3 files to CD without a subdirectory system.	Resulting CDs can be played in all MP3-compatible CD players. (Some CD players — particularly some portable players — that can play MP3 CDs can play <i>only</i> CDs with flat file systems. If your CD player cannot play a CD created with a full file system, try playing a CD written with this option.)	File names appear as "track001.mp3," "track002.mp3," etc.
write an MP3 CD (full file system)	Writes MP3 files to CD with a subdirectory system.	Files are named according to the track title and placed in subdirectories according to artist and album names.	Some CD players (particularly some portable players) cannot play MP3 CDs with full file systems.

erasing cd-rw media

- 1 From the library menu, select CD-Writer, then press **OPTIONS**: 
- 2 Select erase cd-rw.
- 3 Select Yes on the pop-up menu to confirm the operation.

putting your music on a portable device

supported devices

The digital entertainment center supports a number of portable devices for music transfer, including:

- Sonicblue Rio 500
- Iomega HipZip
- SanDisk ImageMate — CompactFlash card reader, MultiMediaCard reader

Look for support for additional devices to be added through software updates. See hp.com/support/de100c for the latest information on supported devices and new functions.

note You cannot transfer music from your portable device to the digital entertainment center.

downloading to a portable device

To download music from your digital entertainment center to a portable device, you first need to connect the device and compile the list of tracks you want to transfer. Then you can refine the list before starting the transfer.

- 1 Connect the USB cable provided with your portable device to the device itself and to the digital entertainment center. (The digital entertainment center has one USB port on the front and two USB ports on the back.)
- 2 If your portable device has a power switch, make sure it's powered on. (If the device is not on or has insufficient battery power, the digital entertainment center may not find or recognize it.) If the device requires media (such as a memory card), ensure that the media is in place.
- 3 From the library menu, select Music or Playlists.
- 4 Navigate down to the appropriate level and highlight the first item you want to add to your portable.

tip

Once you've chosen music files to write to your portable device, the list is accessible until you make the transfer (to access the list, select [Portables](#) from the library menu).

When the transfer is complete, your list of songs is deleted.

To create a list that remains available (such as to write to CD or just to listen to), build a playlist first, then add the playlist to your portable.

See page 40 for instructions on creating a playlist.

 tip

To ensure tracks are transferred without errors, all navigation except [Stop](#) is disabled during the transfer.

DO NOT disconnect the device during a transfer; you could damage your portable device or media and leave the de100c in an unfinished state, requiring a power reset (see “on/off and sleep mode” on page 22).

You can add items track by track, or you can add multi-track items, such as an entire album or a complete playlist.


When the item is highlighted, press OPTIONS: 


- 5 Select add to, then select portable.

The digital entertainment center searches for connected portable devices (this may take a moment).

- 6 From the portable devices listed onscreen, select the device you want to transfer to. As needed, select the appropriate folder or memory location as well. (For information on setting up your portable device’s file structure, see “external devices” on page 71.)


The portable device’s list of contents appears onscreen, including files that were already stored on the device.


- 7 Continue adding items to the add pad by navigating through the music list and pressing ADD: 

- 8 When finished, press OPTIONS: 

The screen displays your list, noting which tracks are already on device, which tracks will fit, and which tracks won’t fit.

- To delete a track from the list, highlight the track, then press OPTIONS. Select delete.
- To change the order of the tracks, highlight a track, then press OPTIONS. Select move, and use the up or down arrow to move the item. When you are done, press SEL.
- To clear the entire list, press OPTIONS, then select clear.

- 9 To transfer the listed tracks to your portable, press OPTIONS:  Select start transfer.

If you want to stop the transfer process, press Stop. 

error message

If you see the message “no portable device present” when your portable device is connected to the digital entertainment center, check the following:

- Is your portable supported? Go to www.hp.com/support/de100c for an updated list of supported players.
- Is your device powered on?
- Is the USB cable securely attached to the portable device and the digital entertainment center? Unplug and reconnect the cable.
- Does the portable device have sufficient power?
- Does the portable device have media in place, if required?

5

listening to internet radio

With the digital entertainment center, you can discover new music and Internet radio stations as well as enjoy your favorites. From the internet radio menu you can:

- play Internet radio stations
- explore new and featured stations
- browse and search for stations by genre, location, and more
- save your favorite stations for quick access

accessing internet radio

To access Internet radio, either:

- press INTERNET RADIO on your remote or front panel:
or
- select Internet Radio from the home menu

INTERNET
RADIO



in this chapter...

understanding internet
radio

— page 54

finding and playing
internet radio stations

— page 56

understanding internet radio

Internet radio is an audio stream, sometimes accompanied by graphics, that you access over the Internet. Thousands of Internet radio stations are available, and because signal distance is not an issue, you can play stations from around the world as well as local favorites.

The following information will help you understand how Internet radio works.

connection

To play Internet radio stations, the digital entertainment center must be connected to the Internet during the entire play session. If you connect via broadband, your connection is always on; if you connect via dial-up, you need to establish the connection first.

At today's transmission rates, both dial-up and broadband users will experience short pauses while playing Internet radio — first as the device connects to the specific station, then as the audio stream is buffered to the listening device.

buffering

Buffering is the method Internet radio stations use to help the music (or other audio) play smoothly. Because the audio stream generally can't be transmitted as quickly as it plays, a certain amount of the stream is sent to the device before play begins. Once the playing device has received enough data, it begins to play.

When listening to Internet radio on any device, you experience these buffering pauses from time to time as the data works to catch up with the play rate.

graphics

Many Internet radio stations transmit graphics — even video — as part of the data stream. When possible, the digital entertainment center displays these graphics on your television screen. However, most user interaction with Internet radio graphics (such as “click here” notices) is designed for browser-based Web access and is therefore not compatible with the digital entertainment center.

station availability

Internet radio stations are sometimes unavailable due to limited broadcast schedules or technical difficulties with the stations themselves. If a station is unavailable, try again later.

note The digital entertainment center cannot record music you hear on Internet radio.

tip

You can navigate around the digital entertainment center while you're playing an Internet radio station.

The audio stream won't stop until you press **Stop** or play another item.

Press **NOW PLAYING** to return to the station's screen.

finding and playing internet radio stations



A brief explanation of the features is all you need to use and enjoy Internet radio.

featured stations

Several Internet radio stations are selected — and regularly updated — to help you sample and discover new music and stations you might not run across on your own. To listen to a featured station, simply highlight it and press SEL or Play.




last station played

To listen to the last station you selected:

- 1 Highlight last station played.
- 2 Press SEL or Play:  or 





browse stations

Select this feature to look for stations by genre. To browse:

- 1 From the Internet Radio menu, select Browse stations.
- 2 Navigate to the genre you want, then press SEL: 
- 3 Navigate to a station name, then press SEL or Play:  or 

my favorites



Select this function for fast access to your favorite stations.

- You can add a station to your favorites at any time: highlight the station and either:
 - press the ADD button: 
 - or
 - press OPTIONS and select add to fav's: 
- To play a station in your favorites list:
 - 1 From the Internet Radio menu, select My favorites.
 - 2 Navigate to the station you want, then press SEL or Play:  or 

search all stations

This function lets you specify search criteria to use to look for Internet radio stations around the world. To search:

- 1 From the Internet Radio menu, select Search all stations.
- 2 To specify your search criteria by category, highlight a category name (Genre, Country, City, or Language) and press SEL, then choose among the terms available. (You can also choose any or skip the category altogether.)
- 3 To search by other station details, select keyword. Using the onscreen keyboard, enter information about the station you're looking for, such as a station's call letters or nickname.

As you enter search criteria, the view stations area shows the number of available stations that match your criteria.
- 4 Select View Stations to list the stations matching your search criteria.
- 5 Highlight a station, then press SEL or PLAY to listen to it:  or 

6

exploring music online

Your digital entertainment center's Internet connection lets you access online music and entertainment, look up artist and album information, purchase music, and more.

The Internet Guide is the place where much of this new discovery takes place — from music videos and movie previews to an online search-and-discover function. You can even purchase CDs online.

Look for new feature and functions to be added to the Internet Guide. For information on these and other updates, see hp.com/support/de100c.

For details on finding and discovering new music through Internet Radio, see “listening to internet radio” on page 53.

accessing your internet guide

To access the Internet guide, either:

- press INTERNET GUIDE on your remote:

or

- select Internet Guide from the home menu



in this chapter...

entertainment features
— page 60

music finder
— page 60

searching & shopping
for music
— page 61

your shopping cart
— page 61

entertainment features




The internet guide menu presents a regularly updated selection of featured entertainment items to be streamed or downloaded.

To access an item, highlight it and press SEL: 

music finder

The music finder lets you find CD or artist information, buy CDs online, manage your shopping cart, and view your order history. Select Music finder and follow the prompts.

In general, navigation through the music finder looks like this:

- To view information (such as artist info or discography), highlight an artist, album, or track, then press INFO: 
- To perform different actions onscreen, such as adding an item to your shopping cart, sorting results alphabetically or by date, or changing the search criteria from artist name (the default) to album or track title, press OPTIONS: 
- To display further details about a highlighted item, press SEL: 


searching & shopping for music

With the digital entertainment center, it's easy to find more music by the artists you already listen to, or to check out related or completely new music.

There are two ways to find music information online:

- When you're listening to a CD or to music from your library, simply highlight an artist, album or track title and press INFO: 

A pop-up menu displays your choices, such as discography and album details. Select the item you want, and view the results online.

For easy ordering options, press OPTIONS: 

- Go to the Internet guide's Music finder to enter a search for any artist, album, or track title. Here you can access the same information (discography, album details, etc.), as well as options to order online.

your shopping cart

When you order music online through the digital entertainment center, you use the onscreen keyboard to enter shipping and billing information — once. The digital entertainment center stores the information you enter (you can choose whether to store credit card information and whether to secure it with a passcode) so your subsequent orders are fast and easy.


note Your personal e-commerce transactions are secured using a variety of access controls and encryption technologies. See the HP Privacy Statement on page 102 or at www.hp.com/support/de100c for more information.

setting your preferences

You can test, view and change many of the digital entertainment center's settings onscreen. From the home menu, select Settings to view the following choices:

- audio settings
- network settings
- scheduling
- external devices
- general information

When you're through viewing or changing settings, you can either:

- return to the settings menu by pressing BACK: 
- or
- go to another mode by pressing its selection button, such as HOME, CD or LIBRARY

Look for more settings options as your system's software is upgraded. For information on these and other updates, see hp.com/support/de100c.

in this chapter...

audio settings — page 64

network settings — page 66

scheduling — page 70

external devices — page 71

general information — page 72

audio settings

encoding rate

The encoding rate determines the sound quality of the tracks recorded to your digital entertainment center. A higher rate (less file compression) improves sound quality, but it also increases file size. At the default rate, 128 kbps (kilobits per second), your digital entertainment center can hold roughly 750 CDs of music (about 9,000 tracks); at 256 kbps it can hold about half that amount.

To change the rate:

- 1 From the settings menu, select Audio Settings, then select Encoding rate.
- 2 Choose a rate from the drop-down menu. Available rates are:
 - 96 kbps: space saver
 - 128 kbps: good (the default rate)
 - 160 kbps: very good
 - 192 kbps: excellent
 - 256 kbps: audiophile

note This setting determines only the encoding rate for CDs recorded to the digital entertainment center from its internal CD drive. Files downloaded from the Internet, imported from a networked PC (see “copying music from a networked PC” on page 33), or copied from an MP3 CD maintain their original encoding rate through the transfer process.

encoding format

The first available encoding format is MP3; look for additional formats to be added. For information on these and other updates, see hp.com/support/de100c.

audio test

You can test to determine whether your audio connections are working properly.

- 1 From the settings menu, select Audio Settings, then Audio test.
- 2 Select Both channels, Left channel, and/or Right channel.

When you select a test, a 24-second music sample plays. You can choose to End test before the music is finished.

If you don't hear music, make sure:

- your receiver's audio input setting is set to the correct input device
- the volume is set high enough and is not muted
- the audio cable is connected properly between your receiver and your digital entertainment center
- your stereo's existing audio cables are connected from the receiver to your speakers

If your left and right channels seem reversed, make sure your audio cable connectors are color matched to the jacks: red to red, white to white.

network settings

Select network settings to view or change your digital entertainment center's Internet and home networking properties. For more in-depth information on these settings and on home networking, see "installing and setting up" on page 75.

From the network settings screen, you can choose to modify your basic settings or to show your advanced network settings.

basic settings

Displayed onscreen are your current network settings (those you specified when you set up your digital entertainment center for Internet access, and/or changes you've made since then). If you change your Internet connection — upgrade to broadband, switch ISPs, change your password, etc. — you'll need to make appropriate changes on the digital entertainment center. To change these settings:

- From the settings menu, select Network Settings, then select Modify basic settings. Follow the onscreen instructions.

internet connection

Choose Dial-up or Broadband.

- dial-up

If you're configuring your system for dial-up Internet connectivity, the following settings appear onscreen, and you can accept or change each one.

- Internet service provider (ISP)
- Dialing prefix
- Dial-up number
- Username
- Password
- Web proxy (if required)

For detailed instructions, see "installing and setting up" on page 75.

■ broadband

If you're configuring your system for broadband Internet connectivity, the digital entertainment center tries to auto-configure the network setup (through DHCP). If the auto-configure fails, or if you choose to modify the settings, you can accept or change each of the following settings onscreen:

- Connection type
- IP address
- Network mask
- Gateway
- Name server
- Web proxy

For detailed instructions, see "installing and setting up" on page 75.

advanced settings

When you select Advanced network settings, the settings outlined below appear onscreen.

host name

To set the host name:

- 1 From the settings menu, select Network Settings, then select Advanced network settings.
- 2 Select Modify advanced settings, then select Host name.
- 3 Specify the fully qualified host name for your digital entertainment center (host name and domain in the format "hostname.domain"). You can select any host name you choose, as long as it is unique on your network. If you or your ISP have not specified a domain name for your home network, use .lan as the domain.

home networking

All home networking parameters are configured (and networking is enabled) for broadband users who are sharing a broadband connection through a router. Dial-up users can install the digital entertainment system onto a home network by entering the appropriate IP address, network mask, gateway and name server. See “installing and setting up” on page 75 for information about these settings.

- 1 From the settings menu, select Network Settings, then select Advanced network settings.
- 2 Select Modify advanced settings, then select Home networking.
- 3 Make changes as appropriate.

file sharing

To copy music files from your PC to your digital entertainment center across your home network (see “copying music from a networked PC” on page 33), you must enable file sharing on your digital entertainment center.

The default setting is to have file sharing disabled. If your digital entertainment center is not protected from the Internet (by, for example, a router that serves as a firewall), you may wish to keep file sharing disabled while you’re not using it, to keep outside users from accessing your digital entertainment center.

To enable file sharing:

- 1 From the settings menu, select Network Settings, then select Advanced network settings.
- 2 Select Modify advanced settings, then select Enable file sharing.
- 3 Specify your network’s workgroup name. Select Done to accept the default (WORKGROUP) or select Edit and use the onscreen keyboard to make changes. You can find your home network’s workgroup name in your PC’s network settings.

To disable file sharing, select Disable file sharing.

prompt before dialing

If you connect your digital entertainment center to the Internet via dial-up, you can choose whether to be prompted with a yes/no choice each time the device prepares to make an Internet connection. The default setting is to prompt the user. (If you connect via broadband, this setting is Not applicable.)

- 1 From the settings menu, select Network Settings, then select Advanced network settings.
- 2 Select Modify advanced settings, then select Prompt before dialing.
- 3 To turn prompting:
 - off, select No.
 - on, select Yes.

scheduling

Select Scheduling to view your system's time and date, and to view or change your time zone or update time.

time and date

The digital entertainment center sets an internal clock and calendar the first time it connects to the HP Digital Entertainment Portal. The hour is determined according to the time zone you set.

time zone

This was originally set during the installation and setup process. To change the time zone:

- 1 From the Settings menu, select Scheduling, then select Time zone.
- 2 Select your time zone from the drop-down menu, scrolling up or down to see all the choices.

update time

The update time is the hour during which your digital entertainment center performs system updates, possibly connecting to the Internet to download upgrades (see page 21 for more information). The update time is pre-set to occur during the middle of the night, when you are not likely to be using the device and the phone line is likely to be free (in case a dial-up connection is used). You can change the hour during which update occurs, but not the time within that hour; the minute is set randomly to prevent traffic peaks at the portal.

To change the update time:

- 1 From the Settings menu, select Scheduling, then select Update time.
- 2 Select an hour from the drop-down menu, scrolling up or down to see all the choices.

external devices

Select external devices if you need to specify a folder when you copy music to your portable device. (Check your portable player's instructions to determine whether it requires a folder and whether the folder needs a specific name.)

To specify the folder setting:

- 1 From the Settings menu, select External devices.
- 2 With Music player folder selected, press SEL.
- 3 Using the drop-down menu, select the appropriate choice:
 - Choosing Root Folder lets you add music files to the top level, or root folder, of your portable device.
 - Choosing My Documents or My Music lets you view and add to second-level folders on your portable device. It also creates the folder if it doesn't yet exist on the device.

note If you're copying music files to a CompactFlash card for use in a pre-568 series HP Jornada, your music files must be copied to a folder called "My Documents." Select **My Documents** on the **external devices** settings screen, and select the **My Documents** folder when you perform the copy operation.

supported devices

The HP Digital Entertainment Center supports a number of portable devices for music transfer, including:

- Sonicblue Rio 500
- Iomega HipZip
- SanDisk ImageMate – CompactFlash card reader, MultiMediaCard reader

tip

Support for additional devices will be added through software updates. You may see additional choices on the external devices settings screen.

See hp.com/support/de100c for updated information on supported devices and additional functions.

tip

Registration lets HP help you by quickly directing any service calls you may make. It also lets you choose whether HP may contact you to keep you up to date on product information and offers.

Entering your registration information also makes shopping online easier: Your address is automatically entered in the “ship to” and “bill to” fields. (You can easily accept or override the address.)

You can change your input and your choices at any time, and the updated information will be sent to HP online.

general information

registration info

You can register your digital entertainment center online from the initial setup screen, or you can enter or update the information through settings. Registration includes information on where your de100c was purchased, as well as:

- name
- mailing address
- phone number
- e-mail address

The registration process also includes options to allow HP to contact you via mail, phone, or e-mail with information and/or offers. For more information on these choices and to find out how HP protects your personal information, see the HP Privacy Statement on page 102.

To add or change your registration information:

- 1 From the settings menu, select general information, then Registration info.
- 2 Select Modify settings.
- 3 Follow the prompts, using the onscreen keyboard to make text entries.

about your de100c

From the settings menu, select general information, then about de100c to view the following:

- Serial number of your digital entertainment center
- Software version installed on your digital entertainment center
- Free hard disk space (what percentage of the digital entertainment center's 40 GB hard drive is available)

If you need to call HP Customer Care for support, you may be asked for this information.

copyright information

From the settings menu, select general information, then copyright information to find copyright details on technologies and information services used by the digital entertainment center.

installing and setting up

This chapter details your digital entertainment center's installation and configuration.
For additional information, go to www.hp.com/support/de100c.

8

in this chapter...


- step 1: get ready — page 76
- step 2: connect — page 78
- step 3: check setup — page 82
- step 4: configure — page 84
- step 5: connect to the internet — page 85
- step 6: register — page 91
- finding network settings on your PC — page 92

step 1: get ready

- Unpack your digital entertainment center
- check your internet readiness
- choose a location.

unpack your digital entertainment center

Your box contains the following components.



note Save your box and packing materials. They provide the safest way to transport your digital entertainment center.

check your internet readiness

- **dial-up:** 56k modem is built-in.

Some connection methods are not supported. Dial-up support excludes Internet Service Providers that rely on proprietary software, such as AOL® and CompuServe®, and free ISPs that require a Web browser to display banner ads.

No additional equipment is required.

- **broadband:** Connecting through your DSL or cable modem (external modem required), or other broadband connection.

You need additional equipment:

- Router (required). A router lets you share the broadband connection between your de100c and a PC or other Internet-connected device. See your router's manual for details on router connections and configuration.
- Ethernet cable (optional). If your router or home network uses an Ethernet connection, purchase this cable separately. Home PNA users (home phonenumber network): use the phone cable supplied.

choose a location

Place your digital entertainment center where you can easily connect it to:

- your television
- your stereo or audio/video receiver
- an Internet connection (wall jack or router connection)
- a power outlet


caution Do not block the airflow vent on top of the digital entertainment center.

The digital entertainment center's infrared receiver requires an unobstructed signal from the remote control. If you place your digital entertainment center inside a cabinet, be sure the blue window area is not blocked from view. (Placing it behind glass is fine.)

step 2: connect

- connect the audio
- connect the video
- connect dial-up or broadband
- power up

The instructions provided here refer to the diagram below.



This illustration shows a typical configuration. Your setup may differ.


connect the audio

See “a” on the diagram on page 78.

- 1 Connect one end of the audio cable to the de100c’s analog OUT jacks, matching red to red, white to white.
- 2 Connect the other end to one set of your receiver’s audio IN jacks, matching red to red, white to white.

Your receiver has several sets of input jacks. Connect the de100c to the CD input jacks or an AUX set of jacks.

Be sure to set the receiver’s audio input to the corresponding mode when you use your de100c, as shown here:



note Digital audio capability is available through the de100c’s OPTICAL and COAX ports. To use them, purchase the appropriate cables separately.

connect the video

See “b” on the diagram on page 78.




- 1 Connect one end of the composite video cable to the de100c’s composite video OUT jack.
- 2 Connect the other end to your TV’s composite video IN jack.

alternatives

- If you use an audio/video receiver, you can connect the video cable to the de100c’s video OUT jack and to a video IN jack on your receiver. Audio and video connections from the de100c must enter the receiver within the same device group (for example, an AUX group).
- If your TV does not have a composite video IN jack available for use but another device in your system (such as a VCR) does, you can connect the de100c to that device’s video IN jack. With this daisy-chained method, the device the connection passes through must be powered on when you use the de100c.
- The de100c also has S-video and VGA connections. To use one of these outputs, purchase the appropriate cable separately.

connect dial-up or broadband

Refer to “c” on the diagram on page 78. Follow the instructions in the appropriate column in the table below.

dial-up	broadband: Ethernet	broadband: Home PNA
<p>Use the phone cord provided:</p>  <ol style="list-style-type: none"> 1 Connect one end of the phone cord to one of the de100c’s phone jacks. 2 Connect the other end to a phone jack in your home. 	<p>Use your purchased Ethernet cable:</p>  <p>If your router or home network requires an Ethernet connection:</p> <ol style="list-style-type: none"> 1 Connect one end of your Ethernet cable to the de100c’s Ethernet port. 2 Connect the other end to your router (or to a networked RJ45 jack in your home). 	<p>Use the phone cord provided:</p>  <p>If you have a home phoneline network (your home is networked to your router via telephone wire within the walls):</p> <ol style="list-style-type: none"> 1 Connect one end of the phone cord to one of the de100c’s phone jacks. 2 Connect the other end of the phone cord to a networked phone jack in your home.

power up

Refer to “d” on the diagram on page 78.

- 1 Connect the power cord to the de100c and plug it into a grounded wall outlet.
- 2 Put the batteries into the remote control.

tip

To share a household phone jack between your de100c and a telephone, either:

- plug the phone splitter into your household phone jack, then connect the de100c and the phone to the splitter
- or
- plug your telephone’s cord into the de100c’s second phone jack

step 3: check setup

turn on your system

Turn on all components in your setup:

- your digital entertainment center
- your television (with video input set to the appropriate input source)
- your receiver (with audio input tuned to the appropriate setting)
- any daisy-chained components (such as a VCR)

After a short startup sequence, you will see welcome to the digital entertainment center on your TV screen.

note If you don't see the welcome screen, see "about component with multiple inputs" below, and refer to the table on page 83.

Your digital entertainment center is now connected. Proceed to "step 4: configure" on page 84.

about component with multiple inputs

In many entertainment system setups, it is common for components to get input from more than one source. For example, your TV might take input from a VCR and a gaming system, or you might pass video from both your cable system and your digital entertainment center through your VCR. Any component that can accept multiple inputs provides a way for you to choose which input you want the component to "pay attention to" — which source it should pass on to the connected output device (TV or speakers).

If any component in your digital entertainment setup is using multiple input sources, you'll need to set the component to accept or display the correct input. The table on the next page outlines some possible scenarios and solutions. You may need to refer to the specific component's owners guide for instructions.

this component...	may receive this input...	so you need to...
TV	<ul style="list-style-type: none"> — cable TV — de100c video content — content from other video sources, such as a VCR or DVD player, or video game system 	<p>Set your TV to display the desired video input:</p> <ul style="list-style-type: none"> — Look on your TV's remote for an Input or Input Sel button (or similar) and scroll through the options. — Some TVs use the channel changer to select the input: set your TV to the lowest channel, then press the "channel down" button to access another input line. — If your TV has an onscreen menu, go to the menu and look for an input setting there.
VCR	<ul style="list-style-type: none"> — cable TV — de100c video content 	<p>Set your VCR to pass the desired video input:</p> <ul style="list-style-type: none"> — Look on your VCR's remote for an Input or Input Sel button and scroll through the options. — Some VCRs use the channel changer to select the input: set your VCR to the lowest channel, then press the "channel down" button to access another input line. On many VCRs the choices are line 1 out or line 2 out.
receiver	<ul style="list-style-type: none"> — radio stations (from its internal tuner) — de100c audio from the audio cable — sound from another entertainment device, such as a tape deck, VCR or DVD player 	<p>Set the receiver's audio input mode to match the set of jacks you used when you connected the de100c to the receiver (typically CD or AUX):</p> <ul style="list-style-type: none"> — Look on the receiver's front panel for buttons or a knob to set the audio input. — Look on your receiver's remote for an Input or Input Sel button and scroll through the options.

tip

If you are troubleshooting your audio and video settings, start with the digital entertainment center and work your way to the output components — your television for video, and your speakers for audio. Check your connections and settings along the way.

This will help you ensure that each component is set correctly before you spend time adjusting the more remote components. For example, you should set your VCR to pass on the desired input, *then* make sure the TV is set to display input from the VCR.

step 4: configure

Using the remote control, follow the onscreen instructions to finish your system setup and connect to the Internet. Use the arrow keys to navigate among the selections; press SEL to choose an option.

You can change these settings (and perform the audio test) at any time: From the home menu select settings. See “setting your preferences” on page 63 for more information.

test the audio

Check the audio connection for left, right, and/or both channels.

If you don't hear music during the test, check that:

- the audio cables are connected properly between your receiver and your digital entertainment center
- your receiver is set to the correct input device (see “connect the audio” on page 79)
- your receiver's volume is set high enough (and is not muted)
- your stereo's existing audio cables are properly connected from the receiver to your speakers

If your left/right channels seem reversed, make sure your audio cable connectors are color-matched to the jacks: red to red, white to white.

note See “about component with multiple inputs” on page 82 and refer to the table on page 83 for more discussion on device input settings.

set the time zone

Select your time zone. The digital entertainment center automatically set its internal clock. (There is no additional way to set the clock.)

step 5: connect to the internet

dial-up

To set up your dial-up connection, you need to:

- gather the ISP information you need to enter (below)
- test the dial-up connection (page 87)
- register (page 91)

gather information

Because the digital entertainment center accesses the Internet in the same way your PC does, most of the information to be entered for dial-up connection is accessible on your PC.

Locate the following information within your PC's network settings and note it here, then follow the onscreen instructions to enter it on the digital entertainment center. (For information on using the onscreen keyboard, see "typing with the onscreen keyboard" on page 18.) For any information you cannot locate on your PC, you may have a printout from your ISP detailing the information; or call your ISP's information/support line.

- Internet Service Provider (ISP) _____
The digital entertainment center can automatically configure certain settings according to the ISP it's connecting to. Onscreen, select your ISP or Other.
- Dialing prefix _____
If your PC uses a dialing prefix to access your ISP – such as 9 for an outside line or *70 to disable call waiting – you probably want (and may need) the digital entertainment center to use the same dialing prefix. If you use more than one prefix, you can simply enter them together (for example, "9*70") or separated by commas (for example, "9,*70").
- Dial-up number _____
This is the number your PC dials to reach your ISP. When you enter the number onscreen, punctuation is not required, although dashes are allowed. Include "1" and area code only if your PC needs to dial them. Enter only one phone number.

tip

about the dial-up connection

If your digital entertainment center is configured for dial-up, any operation that requires an Internet connection causes the digital entertainment center to:

- dial to establish the connection
- perform the operation
- hold the connection open for a short period of time (a couple of minutes)

This hold time lets the digital entertainment center perform subsequent Internet operations without requiring a new connection each time.

- Username _____
(Sometimes called Account Name or Login Name.) Your username is usually case sensitive, so you may need to use the onscreen keyboard's case button to switch between lower-case and capital letters.
- Password (memorize)
To maintain your password's confidentiality, you may wish to memorize it instead of writing it here. Your password is usually case sensitive, so you may need to use the onscreen keyboard's case button to switch between lower-case and capital letters. When you select done, the onscreen display will show asterisks.

Your password is also displayed as asterisks on your PC screen. If you don't know your password, you may need to call your ISP's information/support line.

note Under rare circumstances, your password may contain characters that aren't available on the digital entertainment center's onscreen keyboard. If it does, you'll need to change the password you use to connect to your ISP through your PC and your digital entertainment center. Some ISPs let you change the password on your PC using software they provide; others require that you call their support number to initiate a password change.
- Web proxy (if applicable) _____
Most ISPs do not require use of a proxy server for Web access. If you don't need to enter a Web proxy, select Next, then Test dial-up connection.

If you do need to enter a Web proxy (if your PC Web browser's settings show a value for "Web Proxy" or "Proxy Server"), select Edit from the web proxy screen and use the onscreen keyboard. Specify the server and port as:
 - proxyServer.domain:portNumber (for example, proxy.isp.com:8088)
 - or
 - IP_address:port (for example, 15.2.147.1:88)

test the dial-up connection

You can test your dial-up connection with or without entering a proxy server.

Once the success! screen appears, your Internet setup is complete.

- error messages
 - If you receive an error message while entering information, correct the entry as indicated.
 - If you receive an error message while testing the Internet connection, follow the onscreen instructions or see www.hp.com/support/de100c for troubleshooting advice.

about the connect icon

Note the “connect” icon on your TV screen and the front panel display:



When the icon is:

- yellow, your digital entertainment center is in the process of connecting to the Internet
- white, your Internet connection is active

tip

If you need your phone line while the digital entertainment center is connected to the Internet via dial-up, the fastest way to break the connection and free the line is to quickly press and release the digital entertainment center's [Power](#) button.

broadband

router

If you have not yet installed a router to network your broadband connection, set up and configure your router (see your router's instructions) before proceeding. If your router software offers a choice, we strongly recommend that you configure it for DHCP (dynamic host configuration protocol) so your router can automatically configure the digital entertainment center (and other Internet-connected devices).

connecting

- 1 Select Broadband from the internet connection screen, then select Ethernet or Home PNA (home phoneline). The digital entertainment center tries to automatically find the information it needs through your network.

When the auto-setup success screen appears, select Accept network settings. (HP strongly recommends against modifying these settings.)

If your auto-setup fails, follow the onscreen instructions. See "if auto-setup fails" on page 89, or refer to www.hp.com/support/de100c for troubleshooting advice.

- 2 Enter a Web proxy (if required) and test the connection.

Most ISPs do not require use of a proxy server for Web access. If you don't need to enter a Web proxy, select Next, then Test Internet connection.

If you do need to enter a Web proxy (if your PC Web browser's network settings show a value for "Web Proxy" or "Proxy Server"), select Edit from the web proxy screen and use the onscreen keyboard. Specify the server and port as:

— proxyServer.domain:portNumber (for example, proxy.isp.com:8088)

or

— IP_address:port (for example, 15.2.147.1:88)

if auto-setup fails

If automatic configuration fails, first check the physical connection from your de100c to your network or router. If the connection is correct, choose Manual Setup and perform the following steps. See www.hp.com/support/de100c for further troubleshooting advice.

1 Gather the information.

Gather the following information (most of it is stored in your PC's network settings on your router) and note it here. For specific instructions on finding this information on your PC, see "finding network settings on your PC" on page 92.

- Connection type Ethernet Home PNA

Choose the type of cabling you use to connect your digital entertainment center to your router or network. Ethernet cable (usually Category 5, or Cat 5) terminates in RJ45 (8-prong) connectors. Home PNA refers to home phonenumber networking based on regular telephone wire that terminates in 4-prong (RJ11) jacks.

- Internet address _____

Assign an Internet address (IP address) for your de100c. The Internet address is a numeric value; for most home networks it is 192.168.xx.xx, where xx represents numbers specific to your system. You'll need the complete address, including digits and periods. See your router's manual to find the range of IP addresses you can use.

- Network mask _____

On your PC, view your network settings to find the network mask (also called the netmask or subnet mask). For most home networks, the network mask is 255.255.255.0.

- Internet gateway _____

On your PC, view your network settings to find the Internet gateway, which is in the format 192.168.xx.xx.

- Name server _____

On your PC, view your network settings to find the name server (also called the domain name server, or DNS), which is in the format 192.168.xx.xx.

■ Web proxy (if required) _____

Most ISPs do not require use of a proxy server. If yours does, specify the server and port as:

— proxyServer.domain:portNumber (for example, proxy.isp.com:8088)

or

— IP_address:port (for example, 15.2.147.1:88)

To determine whether your ISP requires a proxy server, view your PC Web browser's network settings (see "locating the web proxy" on page 94) or call your ISP to ask.

2 Enter the information onscreen.

Follow the onscreen instructions. Select Edit to bring up the onscreen keyboard to enter the appropriate values; select Next to continue to the next step.

note If you receive an error message while entering information, correct the entry as indicated.

3 Test the broadband connection.

When the success! screen is displayed, select Next to return to the initial setup screen.

note If you receive an error message while testing the Internet connection, follow the onscreen instructions or see www.hp.com/support/de100c for troubleshooting advice.

step 6: register

Registering your digital entertainment center has several benefits:

- HP can quickly direct any service calls you may make.
- Shopping online is easier, because your address is automatically entered in the “ship to” and “bill to” fields (you can easily accept or override the address).
- You can choose whether HP may contact you to keep you up-to-date on product information and offers.

note HP keeps all your information private and secure. For more information, see the HP Privacy Statement on page 102 or at www.hp.com/support/de100c.

Following the onscreen instructions, enter your registration information. Select Edit to bring up the onscreen keyboard for entry; select Next to continue to the next step.

finding network settings on your PC

locating the network mask, internet gateway, and name server

Windows 98/Me

- 1 On your desktop, right click on Network Neighborhood.
- 2 Select (left click) Properties.
- 3 From the Network window, choose the Configuration tab.
A list of network components is displayed.
- 4 Scroll to find the TCP/IP setting for the network card that is connected to your home network, and select the card name.
- 5 Left click on Properties.
- 6 Select the IP Address tab.
The Subnet mask you need is displayed.
- 7 Select the Gateway tab.
Under Installed Gateways, the first set of numbers is the Internet Gateway you need.
- 8 Select the DNS Configuration tab.
Under DNS Server Search Order, the first set of numbers listed is the Name server you need.

Windows 2000

- 1 On your desktop, right click on Network Neighborhood.
- 2 Select (left click) Properties.
A list of network connections is displayed.
- 3 Right click on the connection to your home network.
- 4 Select Properties.
- 5 In the Properties Window, scroll to Internet Protocol (TCP/IP) and select it.
The Subnet mask, Internet gateway, and Name server you need are displayed.

locating the web proxy

Internet Explorer

- 1 Open Internet Explorer.
- 2 From the Tools menu, select Internet Options.
- 3 From the Internet Options window, select the Connections tab.
- 4 Right click on the LAN Settings button.
- 5 In the LAN Settings window:
 - if Use a Proxy Server is not checked, you don't need a Web proxy
 - If Use a Proxy Server is checked:
 - the address and port you need are displayed (you may need to scroll left and right to see the entire address)
 - the Web proxy you need is formed by the address and port, joined with a colon (address:port)

Netscape

- 1 Open Netscape.
- 2 From the Edit menu, select Preferences.
- 3 From the Preferences window, go to the Category field.
- 4 Under Category, click on the plus sign (+) by Advanced
- 5 Select Proxies:
 - if Direct Connection to the Internet is selected, you don't need a Web Proxy
 - if Automatic Proxy Configuration is selected, you need to call your ISP for the proxy information
 - if Manual Proxy is selected, choose View:
 - in the Manual Proxy Configuration window, the address and port you need are displayed
 - the Web proxy you need is formed by the address and port, joined with a colon (address:port)

support and customer information

support and services

troubleshooting

If you experience problems with your HP Digital Entertainment Center, see the Troubleshooting Guide online at www.hp.com/support/de100c.

hp customer care

If you need assistance or answers to questions regarding your HP Digital Entertainment Center, you can contact HP Customer Care in the following ways:

- Online: go to www.hp.com/support/de100c
- Phone: call 208-323-2551 (English only, U.S. only)

Free phone support is available at the following times for customers whose devices are still within the stated warranty period. This is a toll call. Long distance charges may apply.

Monday through Friday 6 a.m. to 10 p.m. (MST)
Saturday 9 a.m. to 4 p.m. (MST)

After warranty period, a fee of U.S. \$25 per call will be charged to your Visa, MasterCard, or American Express.

9

in this chapter...

support and services
— page 97

hp upgraded warranty
statement
— page 99

warranty statement
— page 100

privacy statement
— page 102

product certifications
— page 105



tip

If your digital entertainment center stops responding, you can reset the system by pressing and holding the **Power** button for six seconds to power off, and then powering on again.

repairs and service

After working with the Customer Care Center, if it is determined that your HP Digital Entertainment Center requires repair/service, you will be instructed on how and where to ship your unit to a repair site. HP pays for the round-trip shipping and handling. The unit will be repaired and returned to you in approximately seven to nine business days from the date of receipt. This service is free for one year from the date you purchased your digital entertainment center.

HP does not warrant that the operation of HP products will be uninterrupted or error-free. If HP is unable, within a reasonable time, to repair or replace any product to a condition as warranted, you will be entitled to a refund of the purchase price (minus taxes) on a pro-rated basis upon prompt return of the product. Refunds within the first 3 months of ownership will be refunded at 100% of purchase price. Refunds within 3-6 months of ownership will be refunded at 85% of purchase price. Refunds within 6-9 months of ownership will be refunded at 55% of purchase price. Refunds within 9-12 months will be refunded at 35% of purchase price.

hp upgraded warranty statement

Protect your investment! Upgrade your standard warranty to three years of service coverage and access to phone support for only \$200. (Coverage begins on product purchase date; local or long distance phone charges may apply.) HP Support Pack Hardware Maintenance Services must be purchased within 180 days of your HP product purchase.

This service is also available for our factory-refurbished products. Available in the U.S. only. Offer is good on HP Digital Entertainment Center only. Only one warranty upgrade per product may be purchased.

The HP Digital Entertainment Center Warranty Upgrade offers:

- three years of access to support six days a week (Monday - Friday, 6 am to 10 pm MST; Saturday, 9 am to 4 pm MST)
- three years of parts and labor
- HP-trained service representatives
- quick resolution of any hardware problems
- technical assistance for installation, product configuration and setup, problem solving and normal operation on your HP product at no cost (excluding local or long distance phone charges) for the duration of the warranty upgrade

To order this upgrade, call (208) 368-7877 and reference H7734A/E.

warranty statement

- 1 HP warrants to you, the end-user customer, that HP hardware, accessories, and supplies will be free from defects in materials and workmanship after the date of purchase, for the period specified above. If HP receives notice of such defects during the warranty period, HP will, at its option, either repair or replace products that prove to be defective. Replacement products may be either new or like-new.
- 2 HP warrants to you that HP software will not fail to execute its programming instructions after the date of purchase, for the period specified above, due to defects in material and workmanship when properly installed and used. If HP receives notice of such defects during the warranty period, HP will replace software media that does not execute its programming instructions due to such defects.
- 3 HP does not warrant that the operation of HP products will be uninterrupted or error free. If HP is unable, within a reasonable time, to repair or replace any product to a condition as warranted, you will be entitled to a prorated refund of the purchase price (minus taxes) upon prompt return of the product.
- 4 HP products may contain remanufactured parts equivalent to new in performance or may have been subject to incidental use.
- 5 Warranty does not apply to defects resulting from (a) improper or inadequate maintenance or calibration, (b) software, interfacing, parts or supplies not supplied by HP, (c) unauthorized modification or misuse, (d) operation outside of the published environmental specifications for the product, or (e) improper site preparation or maintenance.

- 6 HP MAKES NO OTHER EXPRESS WARRANTY OR CONDITION WHETHER WRITTEN OR ORAL. TO THE EXTENT ALLOWED BY LOCAL LAW, ANY IMPLIED WARRANTY OR CONDITION OF MERCHANTABILITY, SATISFACTORY QUALITY, OR FITNESS FOR A PARTICULAR PURPOSE IS LIMITED TO THE DURATION OF THE EXPRESS WARRANTY SET FORTH ABOVE. Some countries, states, or provinces do not allow limitations on the duration of an implied warranty, so the above limitation or exclusion might not apply to you. This warranty gives you specific legal rights and you might also have other rights that vary from country to country, state to state, or province to province.
- 7 TO THE EXTENT ALLOWED BY LOCAL LAW, THE REMEDIES IN THIS WARRANTY STATEMENT ARE YOUR SOLE AND EXCLUSIVE REMEDIES. EXCEPT AS INDICATED ABOVE, IN NO EVENT WILL HP OR ITS SUPPLIERS BE LIABLE FOR LOSS OF DATA OR FOR DIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL (INCLUDING LOST PROFIT OR DATA), OR OTHER DAMAGE, WHETHER BASED IN CONTRACT, TORT, OR OTHERWISE. Some countries, states, or provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.
- 8 HP's limited warranty is valid in any country where the covered HP product is distributed by HP except for the Middle East, Africa, Argentina, Brazil, Mexico, Venezuela, and France's "Departements D'Outre-Mer"; for those excepted areas, the warranty is valid only in the country of purchase. Contracts for additional warranty services, such as onsite service, may be available from any authorized HP service facility where the product is distributed by HP or by an authorized importer.
- 9 FOR CONSUMER TRANSACTIONS IN AUSTRALIA AND NEW ZEALAND: THE WARRANTY TERMS CONTAINED IN THIS STATEMENT, EXCEPT TO THE EXTENT LAWFULLY PERMITTED, DO NOT EXCLUDE, RESTRICT, OR MODIFY AND ARE IN ADDITION TO THE MANDATORY STATUTORY RIGHTS APPLICABLE TO THE SALE OF THIS PRODUCT TO YOU.

privacy statement

HP respects your privacy and is committed to protecting it. HP provides this Privacy Statement to inform you of our privacy policy and practices and of the choices you can make about the way your information is collected and used with this appliance and its services. This privacy statement applies only to the HP Digital Entertainment Center product and HP Digital Entertainment Portal services. To view it online, go to www.hp.com/support/de100c.

This privacy statement covers personally identifiable information, anonymous data collection and aggregate reporting. Personally identifiable information is any information that is associated with your name or personal identity. Anonymous information is data about usage and service operation, reported in aggregate, which is not associated to a specific personal identity. Aggregate information is data collected and summarized for a category of customers or services.

Our policy regarding the privacy of your information covers the five fair information principles: Notice, Choice, Access and Accuracy, Security and Oversight.

Notice

The HP Digital Entertainment Center is designed to give you a flexible, customized and secure listening experience. HP uses the information we collect to understand our customers' listening interests and preferences in order to deliver quality services. HP does this through the collection of anonymous data that is aggregated for analysis. The anonymous information we collect includes Internet Radio station selections, CDDDB database lookups and Entertainment Portal searches. Service providers, working on behalf of HP, will receive anonymous and aggregate data for the purposes of providing a service and ensuring service delivery quality.

Personally identifiable information may be used for account management and to complete downloads, e-commerce or other entertainment transactions. When you register, the personal information we collect includes name, postal mail address, telephone number, e-mail address and HP-wide contact preferences. E-commerce transactions also collect credit card information.

HP does not knowingly collect information from children under the age of 13 and the HP Digital Entertainment Center and Digital Entertainment Portal do not target information to children under 13.

Each HP Digital Entertainment Center has a unique serial number. All HP Digital Entertainment Portal requests, such as catalog searches and CD purchases, include this number – in part to ensure secure communications. If you register the product, the serial number is linked with your personally identifiable information. Neither the serial number nor your personally identifiable information, however, will be linked to the anonymous data HP collects. As HP develops services that rely on additional personal information, such as personal profiling for a customized listening experience, your participation will be requested on an opt-in basis.

Choice

HP will not sell, rent or lease your personally identifiable information to others. HP will not share your personal information with a business partner or any unrelated third party company without your permission. Your permission will be requested before you submit your information.

You can choose to receive product- and service-specific information and HP-wide marketing communications on an opt-in basis. HP-wide communications may include new product information, special offers or possibly an invitation to participate in market research. We give you a choice regarding HP-wide communications by postal mail, e-mail and telephone. You can make your choice at registration or can change your preferences by updating your registration information in the HP Digital Entertainment Center “Settings” area. This option does not apply to communication for the purpose of administering order completion and service or support updates.

HP contracts with third party service providers and suppliers to provide a complete product and customer solution. These suppliers and service providers are called “logical HP”; they act on HP’s behalf and are bound to the HP privacy policy contractually through confidentiality and personal data protection agreements. Suppliers and service providers are required to keep the information received on behalf of HP confidential and may not use it for any purpose other than to carry out the services they are performing for HP. These service providers may change or we may contract with additional service providers in order to provide new services. HP will not share personal information with any other third parties without your permission unless required by law enforcement action or subpoena.

Access & Accuracy

HP strives to keep your personally identifiable information accurate and lets you view and change that information. You access your personal information submitted to the HP Digital Entertainment Center through the “Settings” area.

Security

HP is committed to ensuring the security of your information. To prevent unauthorized access or disclosure, maintain data accuracy and ensure the appropriate use of the information, HP has in place appropriate physical, technical and managerial procedures.

The HP Digital Entertainment Center uses a unique, proprietary public/private key encryption method to ensure secure storage and secure data communication between the HP Digital Entertainment Center and the HP Digital Entertainment Portal. Your personal e-commerce transactions are secured using a variety of access controls and encryption technologies. Credit card numbers are used only for processing payment and are not used for other purposes.

Oversight/Enforcement

As a corporate sponsor, HP is a member of the BBB*Online* Privacy Seal Program and complies with its privacy standards. BBB*Online* is backed by an organization recognized for its expertise and experience in conducting successful national self-regulation programs — the Council of Better Business Bureaus. Further information about this program is available at www.bbbonline.org. HP privacy practices are self-certified to the U.S. Department of Commerce Safe Harbor Program. Local country laws and policies are applied where they differ from those in the U.S.

If you have comments or questions about our privacy policy, please send them to: privacy@hp.com

Rev. September 2001

product certifications

UL, cUL, meets or exceeds FCC Class B Requirements. Laser: CDRH Class 1

Laser Safety

This unit employs a laser. Do not remove the cover or attempt to service this device when connected due to the possibility of eye damage.

CAUTION

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous laser radiation exposure.

Class 1 Laser Product
Klass 1 Laserapparat
Luokan 1 Laserlaite
Klasse 1 Laser-Produkt

DANGER: INVISIBLE LASER RADIATION WHEN OPEN. AVOID DIRECT EXPOSURE TO BEAM.

DANGER: RADIATIONS INVISIBLES DU LASER EN CAS D'OUVERTURE. EVITER TOUT EXPOSITION DIRECTE AU FAISCEAU.

VORSICHT: UNSICHTBARE LASERSTRAHLUNG, WENN ABDECKUNG GEÖFFNET. NICHT DEM STRAHL AUSSETZEN.

ADVARSEL: USYNLIG LASERSTRÅLING VED ÅBNING. UNDGÅ UDS/ETTEELSE FOR STRÅLING.

ADVARSEL: USYNLIG LASERSTRÅLING NÅR DEKSEL ÅPNES. UNNGÅ EKSPONERING FOR STRÅLEN.

VARNING: OSYNLIG LASERSTRÅLNING NÅR DENNA DEL ÄR ÖPPNAD. STRÅLEN ÄR FARLIG.

VARO! NÄKYMÄTÖN AVATTAESSA OLET ALTTIINA LASERSÄTEIL YLLE. ÄLÄ KATSO SÄTEESEN.

CD Laser

Type: Semiconductor laser GaA1As
Wave length: 780 nm (at 25 degrees C)
Output power 2.5 mW (read) 35 mW (write)
Beam Divergence: 60 degrees

Federal Communications Commission R.F. Interference Statement

WARNING: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Changes or modifications to this equipment not expressly approved by Hewlett-Packard could result in violation of Part 15 of the FCC rules.

DECLARATION OF CONFORMITY according to ISO/IEC Guide 22 and EN 45014	
Manufacturer's Name:	Hewlett-Packard Company Colorado Personal Storage Solutions Division
Manufacturer's Address	825 14th Street SW Loveland, Colorado 80537
Declares that the product:	
Product Name:	HP Digital Entertainment Center de100c
Product Number:	L1410A
Product Options:	All
Conforms to the following product specifications:	
Safety:	UL 1950 Third Edition CSA 22.2 No. 950-95
EMC:	CISPR 22: 1997 / EN 55022: 1998 Class B FCC Part 15 Class B
Supplementary Information: This product was tested in a typical configuration.	
This device complies with Part 15 of the FCC Rules of the USA. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.	
September 2001	Regulatory Compliance manager

FCC Declaration of Conformity

According to 47CFR, Parts 2 and 15, Class B Computer Peripherals:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, (2) this device must accept any interference received, including interference that may cause undesired operations. This applies to all product options.

Hewlett-Packard Company
Colorado Personal Storage Solutions Division
Telephone 970-635-1500

September 2001
Regulatory Compliance Manager

index

A

- add button 14
- advanced network settings 67
- airflow vent 77
- album name
 - editing 42
 - retrieving 31
- AOL 77
- arrow buttons
 - onscreen keyboard buttons 19
 - remote and front panel 15
- artist name
 - editing 42
 - retrieving 31
- audio connection 79
- audio settings 64
- audio test 65, 84
- audio/video receiver 80
- auto-setup 88

B

- back button 15
- basic network settings 66
- billing information (buying CDs) 61

- broadband connection
 - cords and cables 81
 - equipment required 77
 - setting up 88–90
 - settings 67
- browsing internet radio 56
- buffering (internet radio) 54
- burning to CD 46
- buttons
 - detailed descriptions 12–17
 - on front panel 11
 - on remote 10
- buying CDs 60

C

- cancel (onscreen keyboard) 19
- case (onscreen keyboard) 19
- CD
 - burning music to 46
 - playing 26
 - recording selected tracks 30
 - recording to the library 28
 - retrieving information 30
 - writing music to 46
- CD button 13

- CD information
 - editing 42
 - retrieving 20, 31
- CD media 46
- CD tray open/close 12
- CD-R 46
- CD-RW 46
- clear (onscreen keyboard) 19
- clearing
 - playlists 41
- CompactFlash card reader 49, 71
- composite video 80
- CompuServe 77
- configuring Internet connection 84–90
- connection, setting up
 - broadband 88–90
 - dial-up 85–87
 - setup diagram 78
- contacting HP 97
- copying music
 - from networked PC 33
 - to a CD 46
 - to a portable device 49
- copyright information 73
- creating playlists 40
- credit card information (buying CDs) 61
- customer support 97

D

- date 70
- delete (onscreen keyboard) 19

- deleting
 - music from library 43
 - playlists 41
- dialing prefix 85
- dial-up
 - about the connection 20
 - number 85
 - phone cord connection 81
 - prompt 20, 69
 - requirements 77
 - setting up the connection 85–87
 - settings 66
- digital audio input 79
- digital audio media 46
- discography 60
- disconnecting (dial-up users) 20, 87
- domain name server (DNS) 89
- done (keyboard button) 19
- down arrow button 15
- downloading to portable device 49

E

- editing CD information 42
- encoding format 65
- encoding rate 64
- erasing CD-RW 48
- error message
 - CD not writable or not present 47
 - no portable device present 51
- ethernet cable 77
- ethernet connection 81, 89
- external devices 71

F

- fan (internal) 12
- FAQs 23
- fast forward button 16
- favorite stations 57
- FCC statement 105
- featured stations 56
- file compression 64
- file format 65
- file sharing 68
- flat file system 48
- folders (portable devices) 48, 71
- frequently asked questions 23
- front panel 11
- front panel display 37
 - when playing a CD 27
 - when playing music in library 37
 - when recording 29
- full file system 48

G

- gateway 89, 92
- general information (settings menu selection) 72
- genre, editing 42
- graphics and Internet radio 55

H

- hard disk space 73
- help 23
- home button 13

- home networking 68
- home phonenumber networking 81, 89
- host name 67
- hp customer care 97
- hp Journada 71
- HPNA (Home PNA) 81, 89

I

- info button 14, 20
- information privacy 102
- infrared receiver 77
- installation 75–95
- internet address 89
- internet connection 20, 66, 77
- Internet Explorer (finding settings) 94
- internet gateway 89, 92
- internet guide 59–61
 - and the dial-up connection 21
 - button 13
- internet radio 53–57
 - and the dial-up connection 21
 - button 13
- internet service provider 85
- lomega HipZip 49, 71
- IP address 89
- ISP 85
- ISPs supported 77

J

- Journada 71

K

keyboard, onscreen 18–19

L

laser safety 105
last station played 56
left arrow button 15
library 35–43

- deleting music 43
- navigation 38
- recording music to 28
- searching in 39

library button 13
library navigation 38

M

media (CD) 46
minimizing dial-up time 32
MP3 CD (writing) 48
MP3 quality 64
MultiMediaCard reader 49, 71
music CD (CD format) 48
music finder 60
music format (for writing a CD) 48
music library 35–43
my documents folder 71
my favorites 57
my music folder 71

N

name server 89, 92
naming a playlist 40
navigation

- in the library 38
- with remote and front panel 15

Netscape (finding settings) 95
network mask (netmask) 89, 92
network settings 66, 92
networking 81, 92
no portable device present 51
now playing button 12

O

onscreen help 23
onscreen keyboard 18–19
options button 10, 14

P

page down (pg dn) button 15
page up (pg up) button 15
password 86
pause button 17
PC, transferring music from 33
phone line availability (dial-up users) 20, 87
phone splitter 81
phone support 97
play button 16
play vs. select 38

- playing
 - CDs 26
 - playlist 41
- playlists
 - clearing 41
 - creating 40
 - deleting 41
 - naming 40
 - playing 41
- portable
 - putting music on 49
- portable devices
 - putting music on 49
 - supported 71
- power button 12
- power cycle 12, 22
- power modes 22
- preferences 63
- privacy statement 102
- product certifications 105
- prompt before dialing 20, 69
- proxy
 - broadband 88, 90
 - dial-up 86
 - locating 94
- purchasing CDs 60

R

- radio station availability 55
- receiver connection
 - audio/video receiver 80
- receiver input 79

- record button 17
- recording
 - CDs to the library 28
 - selected tracks to the library 30
 - tracks to a portable device 49
 - tracks to CD 46
- registration 72, 91
- remote control 10
- repairs 98
- repeat 14
- restart 12, 22
- restoring from screen saver 22
- retrieving CD information 20, 31
- rewind button 16
- right arrow button 15
- ripping (recording to the library) 28
- router 77

S

- safety 105
- SanDisk ImageMate 49, 71
- scheduling 70
- screen saver 22
- searching
 - internet radio 57
 - the library 39
- security 102
- select (SEL) button 15
- select vs. play 38
- serial number 73
- service 98

- settings 63–73
 - about de100c 73
 - advanced network settings 67
 - audio 64
 - audio test 65
 - copyright information 73
 - encoding format 65
 - encoding rate 64
 - external devices 71
 - file sharing 68
 - general information 72
 - home networking 68
 - host name 67
 - Internet connection 66
 - network settings 66
 - prompt before dialing 69
 - scheduling 70
 - update time 70
- setup 75–95
- shipping information (buying CDs) 61
- shopping cart 61
- shuffle 14
- shuffle/repeat button 14
- skip back button 16
- skip forward button 16
- sleep mode 22
- software version 73
- Sonicblue Rio 500 49, 71
- stop button 17
- subnet mask 89, 92, 93

- support
 - e-mail, phone 97
 - web 23, 97
- S-video 80

T

- telephone availability (dial-up users) 20, 87
- time 70
- time zone 70, 84
- track information, editing 42
- track titles 31
- transferring music
 - from networked PC 33
 - supported portable devices 71
 - to CD 46
 - to portables 49
- transport controls 16, 17
- troubleshooting 97
- tv connection 80
- tv display 37
 - when playing a CD 27
 - when playing music in library 37
 - when recording 29
- typing (onscreen keyboard) 18

U

- unwritable disc 47
- up arrow button 15
- update mode 21

- update time 70
- updates and the dial-up connection 21
- upgraded warranty 99
- URLs 23
- username 86

V

- VGA connection 80
- video connection 80

W

- warranty 99–101
- web proxy
 - broadband 88, 90
 - dial-up 86
 - locating 94
- web sites 23
- Windows 2000 (finding settings) 93
- Windows 98/Me (finding settings) 92
- writing tracks
 - to a portable device 49
 - to CD 46

Copyright 2001 Hewlett-Packard Company

Made in USA



L1410-90101

